

TrekTag_® User Guide



Table of Contents

Introduction	3
Configuring your device	5
Download and Install the Mobile Application	. 6
TrekTag Mobile Functions	7
Activating TrekTag® NFC	13
Logging Data	17
Reading Data	18
Sharing Data from the App	19
Deactivating TrekTag® NFC	20
TrekTag Analytics "The Cloud"	22



TrekTag® User Guide

Introduction to TrekTag.

- Graphic Controls is pleased to offer the TrekTag_® package, which consists of:
 - TrekTag_® NFC Temperature Data Logger that communicates via NFC.
 - TrekTag_® Mobile Android Mobile Application and User Interface.
 - TrekTag® Analytics Web Based "cloud" platform for data storage and analysis.
- In order to utilize TrekTag_® NFC Temperature Data Logger, the user will need to have the following:
 - NFC-Enabled Android device running version 4.4 or higher.
 - TrekTag Mobile Application <u>Download the Free App from Google Play here</u>



Topics Covered


- This User Guide will provide step-by-step instructions on how to:
 - Configure your NFC-Enabled Android device so that the NFC feature is ON.
 - Locate the Free App within Google Play and Install on your device.
 - Activate/Deactivate the TrekTag_® NFC data logger.
 - Use TrekTag Mobile device application to read & write data to the logger.
 - Transmit/Share data from the application via email.
 - Login to the cloud platform on the mobile application so that data is automatically pushed to TrekTag Analytics.



Configuring your Device

- Enabling Near Field Communication (you must have an NFC-enabled Android device 4.4 or higher).
 - Select Settings from the Home Screen
 - Open Connections and find NFC
 - Toggle NFC to the ON position










Graphic Controls
Data Recording by Missha

TrekTag® User Guide

Install the Mobile App on Your Device

Download the free Application from Google Play here










TrekTag® User Guide

Using TrekTag. Mobile Application

1. Launch the application from your device.





TrekTag. Mobile Application Settings


2. Open the App features by clicking on the three dots in the upper right.

- 3. The App Features Menu has *Five* sections.
 - I. Account This section allows you to login to your TrekTag® Analytics "cloud" account.
 - a. Enter your email and password to Login
 - b. When properly logged in to your cloud account, the app will display "cloud syncing enabled for [company name]" at the very bottom as show in picture to the right.
 - Data will automatically be pushed to TrekTag® Analytics for storage and management.
 - II. Settings Allows you to customize temperature scale and time zone.
 - a. Select Celsius or Fahrenheit temperature scale.
 - Set the display temperature time stamp as either local time or UTC time.
 - c. Choose either local or UTC time stamp for the exported data.
 - d. Add a default email address to where the exported data files will be sent.

III. Manage Profiles

- a. Use one of the pre-configured profiles or Create your own.
- b. Create up to 3 custom profiles per user.
- c. Designate Profile name, custom recording interval, and upper/lower limit.
- IV. View Previous allows you to recall data from the last tag that was read on the device.
- V. About Displays the version of the app that is currently loaded onto the device.





When the app is running there are four main tabs/functions along the top of the screen; **Control**, **Info**, **List**, **Chart**. The app will default to the Info tab when launched.

- Control this tab is used for activating and deactivating tags.
 - Set temperature logging interval by either choosing a stored profile or manually entering the desired information.
 - b. When the interval is entered, a time is displayed to the right of the interval field. This is the maximum time the TrekTag® will record and save data.
 - Enter the upper and lower limits that the product should be maintained within.
 - d. The notes sections will hold up to twenty (20) customizable characters.



Cloud syncing enabled for GCDEMO



TrekTag® User Guide

- 2. Info View the status of the tag (active or passive), UID, Logging Info, and Temperature Limits.
 - **UID** Unique Identification Number
 - Each tag comes with a unique factory programmed identification number and cannot be changed.

Currently


- Date and Time of last scan
- Current Battery voltage
- - Active Logger is measuring and recording temperature data Passive - The tag is not reading or recording any data.

Logging

- The date and time temperature logging started
- What the interval is (in seconds) between reading/recording
- User defined notes section
- Number of readings captured at the time of last scan
- The average, maximum, and minimum temperatures recorded

Limits

Displays the upper and lower temperature limits





TrekTag® User Guide

3. List


- a. Displays time-stamped temperature readings in a table format
- b Data


Graphic Controls

- Grey rows are within the temperature threshold
- Blue rows are below the temperature threshold limit
- Red rows have exceeded the temperature limit
 - Information can be shared in .csv and .png format




TrekTag® User Guide






- 1. Place a TrekTag® NFC Card on your work surface.
- 2. Launch TrekTag_® Mobile app and place your device within one (1) inch of the TrekTag_® NFC Data Logger.
- 3. A **Retrieving System Information** dialog box will appear as the tag is being read by your device.
 - If Successful, a message will appear at the bottom of the screen indicating that the **scan is completed**.
 - If a problem occurs, a Scanning Error dialog box will appear. You will need to tap OK and re-scan the tag.
- 4. Keep the device steady and within one (1) inch of the tag while it is being activated. Excess movement during a scan can cause an error and the step will have to be repeated.



△II 99% ■ 12:17 PM



- 5. Select the **CONTROL** tab at the top of the screen.
 - a. To select a stored product temperature profile.
 - i. Press the **Select Profile** button
 - ii. Choose the desired profile from the menu
 - iii. The input fields will be populated and the name of the profile will appear next to the select profile button.
 - b. To Manually enter logging parameters
 - Enter logging interval (hh:mm:ss)
 - ii. Enter desired upper and lower temperature limits
 - iii. Notes field can hold up to 20 user customized characters.
 - c. Press the **Activate Tag** button
 - If the Repeat box is checked, tags will be activated with the same information.








TrekTag® User Guide

d. A **Tag Active** message will appear on the screen and the temperature data logger will begin to record.



Graphic Controls





TrekTag® User Guide

- e. Press **FINISH** to complete the activation process. The data logger is now recording and ready to be used.
- f. To confirm that the logger has been activated as intended, scan the tag, and the INFO tab will open. Once the INFO tab opens the data parameters can be verified.
- g. Peel the backing paper off of the tag and apply to the product or area you want to record temperature (e.g. cartons, pallets, cooler wall, climate controlled room, processing areas, transport container, etc.)








TrekTag® User Guide

Logging Temperature Data

- 1. The TrekTag_® NFC temperature data logger will store a maximum of 800 data points.
- The tag will continue to record and store data at the programmed interval until the tag's memory is full or the unit is deactivated.
- 3. The number of readings and tag status can be viewed from the **INFO** tab.

 Start Time: 11/30 10:26:05 AM EST be under the log interval (sec): 1

FULL



♥ * N 🕏 🐃 📶 98% 🗈 12:23 PM



Reading TrekTag. NFC


- TrekTag® NFC can be read via NFC-enabled Android device at any time during the data logging process. If logged into your TrekTag® Analytics account, the data will then automatically be pushed to the "cloud".
- 2. Launch the application and place the device within one (1) inch of the tag to read and retrieve the data.
- 3. Do no move the device until you see a message near the bottom of the screen that says **Scan Completed.**
- 4. Once the data has been retrieved, you can move your device away from the tag and review the data via various tabs within the application (i.e. INFO, LIST, CHART).





Sharing Data from the App

- 1. After reading a tag, select the **LIST** tab.
- 2. Select the sharing icon
- An email is generated with the data in .csv file format and a graphical image of the data. The email will also include a message with the location of sending device (if enabled).
- 4. Send the data to the appropriate receiving parties.








TrekTag® User Guide

- When you are done recording temperature, you can deactivate or stop the TrekTag_® NFC Temperature Data Logger.
- 2. Launch the TrekTag_® Mobile application and move your device to within One (1) inch of the tag that is to be deactivated.
- 3. Select the **CONTROL** tab at the top of the screen.
- 4. Select the **DEACTIVATE TAG** button.
- 5. Do move the device until you see the **TAG PASSIVE/TAG DEACTIVATED** messages. These messages confirm that the data logging has been stopped. Press Finish to complete the process.
- 6. The Temperature data that was recorded is stored on the TrekTag® NFC label.
- **7. NOTE:** If a user reactivates a previously used tag then the tag will clear and overwrite stored data.












TrekTag® User Guide

TrekTag. Analytics "The Cloud"

- 1. Please provide the user's first/last name, email address, and company name. Once a company Administrator has been established, they will be able to add other users to the company account.
- 2. Enter your email and password and SIGN IN
- 3. If you have an account, but forgot your password, select **FORGOT CREDENTIALS**, and you will be able to reset your password to enter the site.




TrekTag. Analytics Login Screen





TrekTag® User Guide

TrekTag. Analytics Dashboard Example





TrekTag® User Guide